

INSTALLATION NOTES - GROUND ANCHOR

Thank you for purchasing the Lockerpod, the secure, affordable, convenient and attractive bike storage solution. Please read all the notes prior to installation.

GENERAL

Lockerpod must be installed on a solid level surface. If the surface is not level the door may not close square to the door frame which could make closing and securing the door more difficult. If the Ground Anchor accessory is used, it must be fitted prior to Lockerpod installation.

OXFORD GROUND ANCHOR FITTING

The Ground Anchor should be installed into the floor around 75cm from the front lip of the Lockerpod. Bear in mind that your cycle lock needs to pass through the anchor and through your bike frame.

Offer the Ground Anchor up to the Lockerpod floor and mark an outline along the sides of the Anchor and an additional 4cm beyond each end of the Ground Anchor.

Use a spade bit and drill a hole in each corner of the marked position. Join these holes together using a handsaw and blade.

Place the Ground Anchor in the hole onto the ground below and mark the holes for the Ground Anchor fixings.

Remove the Lockerpod and then follow the installation instructions supplied with the Ground Anchor to fix it to the hard standing.

Once the Ground Anchor is installed replace the Lockerpod and ensure that your cycle lock will comfortably slide through the anchor and follow remainder of Lockerpod installation notes. (Picture of installed ground anchor on main notes)

